





SMS FLATSCREEN L SLIDE






Contents


A.	Vesa Plate 75x75/100x100	1
B.	Screws M4x10	4
C.	Screws M4x20	4
D.	Distance washers	4
E.	Allen Key	2
F.	Screen (Not included)	
G.	Wall bracket (Not included)	



EXPANDER VESA 200x100



SMART MEDIA SOLUTIONS



Contents

A.	Expander Vesa plate 200x100	2
B.	Screw M4x6	4
C.	Screw M4x10 / M5x10	4
D.	Screw M4x20 / M5x20	4
E.	Washers	4
F.	Dist. washers	4
G.	Allen Key	1
H.	Vesa plate (Not included)	

